






Wiring Diagrams | Rotary Mechanisms

DO, DO LOW, GARBY, GARBY COLONIAL and VENEZIA Collections




OPERATION DIAGRAMS:




Wiring Diagrams | Toggle Mechanisms


DIMBLER, VENEZIA and 1950 Collections




ONE-WAY SWITCH




DOUBLE ONE-WAY SWITCH




TWO-WAY SWITCH TWO-WAY SWITCH




TWO-WAY SWITCH INTERMEDIATE SWITCH TWO-WAY SWITCH




TWO-WAY SWITCH DOUBLE TWO-WAY SWITCH TWO-WAY SWITCH




DOUBLE-POLE SWITCH




ELECTRIC BLIND SWITCH



ELECTRIC BLIND PUSH BUTTON





PUSH BUTTON



DOUBLE PUSH BUTTON

Wiring Diagrams | Dimmer Switches


DO, DO LOW, GARBY, GARBY COLONIAL, DIMBLER, VENEZIA AND 1950 Collections




Wiring diagrams | Other Applications

DO, DO LOW, GARBY, GARBY COLONIAL, VENEZIA & 1950 Collections


HOTEL CARD SWITCH, 1 MICROSWITCH - GARBY COLONIAL (37935...)




HOTEL CARD SWITCH, 2 MICROSWITCHES - GARBY COLONIAL (37936...)




IR DETECTOR WITH PUSH BUTTON - GARBY COLONIAL (37750...), 1950 (79750...)






THERMOSTAT - 1950 (797300...)




CONNECTED THERMOSTAT - 1950 (79731...) + SENSOR (7973200)




R/TV-SAT SOCKET



Cable removal:



RJ45 SOCKET



T568B



T568A



For connection as a telephone socket (RJ11 or RJ12), only connect the terminals marked blue and blue/white.